
(Three-Phase PV+ESS Scenario + SmartGuard Networking)



## 1

#### Networking

#### Connecting All Loads to the SmartGuard



\* The figure uses the LUNA2000-(5-30)-S0 as an example.


#### **⚠** DANGER

- An RCD must be installed for the backup load. During off-grid operation, the main circuit breaker does not provide protection. Electric leakage on the loads may result in electric shocks.
- A main circuit breaker with the leakage protection function must be installed. Its rated residual operating current must be ≥ Number of M1 or MAPO inverters x 100 mA or ≥ Number of MBO inverters x 300 mA.

#### ☐ NOTE

- Both the EMMA in the SmartGuard and the Smart Dongle provide communication capabilities. Only either of them can be installed in a power plant for networking. Otherwise, communication between devices will be abnormal.
- If a charger is configured, the charger must be installed on the non-backup load port.

#### Connecting Some of Loads to the SmartGuard



Issue: 02

Date: 2024-07-15

#### ☐ NOT

The three-phase SmartGuard supports a maximum load current of 63 A. If the load current exceeds 63 A, only some of loads can be connected to it. In addition, a power meter needs to be connected between the three-phase SmartGuard and the main circuit breaker.


#### (Three-Phase PV+ESS Scenario + SmartGuard Networking)




1

#### **Networking**

If the main circuit breaker's rating is 63 A or less, you can connect all or some of the loads to the SmartGuard. However, if the rating is greater than 63 A, you can connect only some of the loads to the SmartGuard. (Dashed boxes indicate optional components.)



Loads connected to the SmartGuard (dashed boxes indicate optional components)



- (A) Load not connected to the SmartGuard
- (B) Backup load


(C) Non-backup load

(D) Power meter

(E) AC power distribution box

#### 2

#### **Product Overview**



Component	Model	Description
Energy storage system (ESS)	SUN2000-(3KTL-10KTL)-M1 SUN2000-(12K-25K)-MB0 series SUN5000-(17K, 25K)-MB0 series SUN2000-(5K-12K)-MAP0 series SUN5000-(8K, 12K)-MAP0 series  LUNA2000-(5-30)-S0 LUNA2000-(7, 14, 21)-S1	<ul> <li>M1/MB0: Only one inverter is supported.</li> <li>MAP0: A maximum of three inverters are supported.</li> <li>The SUN2000-(5K-12K)-MAP0 inverter cannot be cascaded with other inverters.</li> <li>SUN5000 inverters cannot be cascaded with SUN2000 inverters.</li> <li>Optimizers must be configured for all PV modules connected to a SUN5000 inverter. Otherwise, the inverter cannot be started.</li> <li>Each M1/MAP0 can connect to a maximum of two ESSs, and each MB0 can connect to a maximum of four ESSs. (each battery terminal can connect to a maximum of two batteries)</li> <li>The LUNA2000-(5-30)-S0 and LUNA2000-(7, 14, 21)-S1 cannot</li> </ul>
		<ul> <li>connect to the same inverter in a parallel system.</li> <li>If inverters are cascaded, the LUNA2000-(5-30)-S0 and LUNA2000-(7, 14, 21)-S1 cannot connect to different inverters.</li> </ul>
SmartGuard	SmartGuard-63A-T0 SmartGuard-63A-AUT0	Works with the inverter, ESS, grid, and home appliances to achieve smart management on home power consumption, grid detection, and on/off-grid switchover.
Smart PV Optimizer	SUN2000-450W-P2 SUN2000-600W-P MERC-600W-PA0 MERC-(1300W, 1100W)-P	For details about the optimizer supported by the inverter, see:  SUN2000 Smart PV Optimizer User Manual  MERC-600W-PA0 Smart PV Optimizer User Manual  MERC-(1300W, 1100W)-P Smart PV Optimizer User Manual

#### ∩ NOTE

- 1. The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.
- 2. For details about the solution components, installation, and cable connections, see the corresponding user manuals and quick guides.
- 3. The cable colors involved in this document are for reference only. Select cables in accordance with local cable specifications.

(Three-Phase PV+ESS Scenario + SmartGuard Networking)



WiFi/FE

## 3

#### Cable Connections (Three-Phase Inverter M1/MB0 + ESS S0 + SmartGuard)

Inverter

COM

3

**PV** strings

(with optimizers)

AC


4 ← 2


16<del>←+</del>4


# ▶ DANGER Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur. An RCD must be installed before the backup load. During off-grid operation, the main circuit breaker does not provide protection. Electric leakage on the load may result in electric shocks. A main circuit breaker with the leakage protection function must be installed. Its rated residual operating current must be ≥ Number of M1 inverters x 100 mA or ≥ Number of MB0 inverters x 300 mA..

#### NOTICE

- Signal cables must be outdoor shielded twisted pair cables.
- Only one inverter can be connected to the SmartGuard.
- The PEN of the SmartGuard-63A-T0 backup power port must be connected, but the PEN of the SmartGuard-63A-AUT0 backup power port does not need to be connected.







SmartGuard

**Three-phase SmartGuard** 

Ν

PE

L1

L2

L3

Ν

PE

L1

L2

backup

PDU for

on-backup L3

GRID/ATS-N

GRID/ATS-PE

BACKUP LOAD-L1

BACKUP LOAD-L2

BACKUP LOAD-L3

BACKUP LOAD-N

**BACKUP LOAD-PE** 

NON-BACKUP LOAD-L1

NON-BACKUP LOAD-L2

NON-BACKUP LOAD-N

NON-BACKUP LOAD-PE

NON-BACKUP LOAD-L3 | SmartGuard

**EMMA** 

COM1

Cable Type

No. Cable Connection Description

Method 1: Use DO dry contacts to directly drive the SG Ready heat pump. The max. capability of the DO dry contacts is 12 V DC@1 A.

Method 2: Use a 12 V@30 mA power supply to drive the external relay. Choose the proper contact capability of the external relay according to the SG Ready heat pump port.

Cable	NI-	One	End	The Other End		
Type	No.	Component	Port	Port	Component	
Signal	12	EMMA	WAN	LAN	Router	
Signal cable	13	Charger	FE	LAN	Router	

(Three-Phase PV+ESS Scenario + SmartGuard Networking)

RAT.


BAT+

BAT-

RAT+



#### Cable Connections (Three-Phase Inverter M1/MB0 + ESS S1 + SmartGuard)



- Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks
- An RCD must be installed before the backup load. During off-grid operation, the main circuit breaker does not provide protection. Electric leakage on the load may result in electric shocks.
- A main circuit breaker with the leakage protection function must be installed. Its rated residual operating current must be ≥ Number of M1 inverters x 100 mA or ≥ Number of MB0 inverters x 300 mA..

#### NOTICE

- Signal cables must be outdoor shielded twisted
- Only one inverter can be connected to the SmartGuard.
- The PEN of the SmartGuard-63A-T0 backup power port must be connected, but the PEN of the SmartGuard-63A-AUT0 backup power port does not need to be connected.

Cable Connection Description Method 1: Use DO dry contacts to directly drive the SG Ready heat pump. The max. capability of the DO dry contacts is 12 V DC@1 A. Method 2: Use a 12 V@30 mA power supply to drive the external relay. Choose the proper contact capability of the external relay according to the SG Ready

	Cable	NI.	One End		The Other End		
	Type	No.	Component	Port	Port	Component	
	Signal cable	12	EMMA	WAN	LAN	Router	
		13	Charger	FE	LAN	Router	

heat pump port.

NON-BACKUP LOAD-L1

NON-BACKUP LOAD-L2

NON-BACKUP LOAD-L3

NON-BACKUP LOAD-N

PDU for

COM-2

COM-3

COM-4

SmartGuard

COM-4

COM-8

COM-16

Inverter


(Three-Phase PV+ESS Scenario + SmartGuard Networking)



## 3

PE 1 10 PE Enable- 2 9 CANH nable+ 3 8 CANL 485A 4 7 485B 485A 5 6 485B

#### Cable Connections (Three-Phase Inverter MAPO + ESS SO + SmartGuard Connected to All Loads)



Cable	NIa	One End		The Othe	r End						
Type	No.	Component	Port	Port	Component						
	0	Inverter	PV1+	Positive terminal	DV strings						
	U	inverter	PV1-	Negative terminal	PV strings						
DC power	2	Inverter	BAT+	BAT+	ESS 1						
cable	4	lilverter	BAT-	BAT-	L33 I						
	3	ESS 1	BAT+	BAT+	ESS 2						
	<b>U</b>	L33 1	BAT-	BAT-	L33 Z						
			COM-2 (left)	COM-2 (right)							
			COM-3 (left)	COM-3 (right)							
	4	4	ESS 1	COM-4 (left)	COM-4 (right)	ESS 2					
			•	4	4	49   533	E33 I	COM-7 (left)	COM-7 (right)	ESS 2	
						COM-8 (left)	COM-8 (right)				
							COM-9 (left)	COM-9 (right)			
				COM-7 (right)							
Signal	<b>5</b>		COM: RJ45	COM-4 (right)	ESS 1	ı					
cable	9		able	Inverter	nverter network port	COM-2 (right)					
			_	COM-3 (right)							
	_		COM-1	COM-1							
	6	Inverter	COM-3	COM-2							
		inverted	COM-7	COM-3	SmartGuard						
			COM-9	COM-4							
			COM-5	Generator control							
(16)	SmartGuard	COM-6	signal port	Generator							
			CC.VI 0	3							

Cable	NI-	One	End	One End					
Type	No.	Component	Port	Port	Component				
			AC-L1	INV1-L1					
			AC-L2	INV1-L2					
		Inverter	AC-L3	INV1-L3	SmartGuard				
			AC-N	INV1-N					
			AC-PE	INV1-PE					
		8 Grid	L1	GRID/ATS-L1	SmartGuard				
			L2	GRID/ATS-L2					
AC	AC		L3	GRID/ATS-L3					
power					N	GRID/ATS-N			
cable							L1	BACKUP LOAD-L1	
					PDU for	L2	BACKUP LOAD-L2	Cmart Cuard	
	9	backup loads	L3	BACKUP LOAD-L3	SmartGuard				
		toaus	N	BACKUP LOAD-N					
		L1	NON-BACKUP LOAD-L1						
	PDU for	L2	NON-BACKUP LOAD-L2	C					
	10	non-backup loads	L3	NON-BACKUP LOAD-L3	SmartGuard				
		loaus	N	NON-BACKUP LOAD-N	]				

Cable	NIa	One E	nd	The Other End	
Type	No.	Component	Port	Port	Component
	14	SmartGuard	DI2+	Position feedback	Generator
Signal			DI2-		
cable	15	SmartGuard	DI1+		ATS
			DI1-		A13

Cable Type	No.	Cable Connection Description
Signal cable	1	Method 1: Use DO dry contacts to directly drive the SG Ready heat pump. The max. capability of the DO dry contacts is 12 V DC@1 A. Method 2: Use a 12 V@30 mA power supply to drive the external relay. Choose the proper contact capability of the external relay according to the SG Ready heat pump port.


Cable	No	One End		The Other End	
Type	No.	Component	Port	Port	Component
Signal cable	12	EMMA	WAN	LAN	Router
	13	Charger	FE	LAN	Router

(Three-Phase PV+ESS Scenario + SmartGuard Networking)



## 3

#### Cable Connections (Three-Phase Inverter MAP0 + ESS S0 + SmartGuard Connected to Some of Loads)



#### NOTICE

Signal cables must be outdoor shielded twisted pair cables.

Enable- 2 9 CANH nable+ 3 8 CANL

 The PEN of the SmartGuard-63A-T0 backup power port must be connected, but the PEN of the SmartGuard-63A-AUT0 backup power port does not need to be connected.

Cable	No.	One End		The Othe	r End		
Type	NO.	Component	Port	Port	Component		
	1	0	Inverter	PV1+	Positive terminal	DV stuin se	
	U	mverter	PV1-	Negative terminal	PV strings		
DC power	2	Inverter	BAT+	BAT+	ESS 1	_	
Cable	4	liivertei	BAT-	BAT-	L33 I		
	3	ESS 1	BAT+	BAT+	ESS 2		
	9	L33 I	BAT-	BAT-	L33 Z		
			COM-2 (left)	COM-2 (right)			
			COM-3 (left)	COM-3 (right)			
	4	ESS 1	COM-4 (left)	COM-4 (right)	FCC 2		
		4	E33 I	COM-7 (left)	COM-7 (right)	ESS 2	
					COM-8 (left)	COM-8 (right)	
			COM-9 (left)	COM-9 (right)			
	5			COM-7 (right)			
Signal			COM: RJ45	COM-4 (right)	ESS 1	I	
Cable		Inverter	network port	COM-2 (right)			
				COM-3 (right)			
			COM-1	COM-1			
			COM-3	COM-2			
	6	Inverter	COM-7	COM-3	SmartGuard		
			COM-9	COM-4			
	40		COM-5	Generator control			
	16	16 SmartGuard	COM-6	signal port	Generator		
						_	

Cable	NI-	One End		One End	
Type	No.	Component	Port	Port	Component
			AC-L1	INV1-L1	
			AC-L2	INV1-L2	
	<b>7</b>	Inverter	AC-L3	INV1-L3	SmartGuard
			AC-N	INV1-N	
			AC-PE	INV1-PE	
			L1	GRID/ATS-L1	
		Grid	L2	GRID/ATS-L2	SmartGuard
AC	wer		L3	GRID/ATS-L3	
power			N	GRID/ATS-N	
cable			L1	BACKUP LOAD-L1	
	9	PDU for	L2	BACKUP LOAD-L2	SmartGuard
		backup loads	L3	BACKUP LOAD-L3	SiliartGuaru
		toaus	N	BACKUP LOAD-N	
			L1	NON-BACKUP LOAD-L1	
	10	PDU for	L2	NON-BACKUP LOAD-L2	SmartGuard
		non-backup loads	L3	NON-BACKUP LOAD-L3	SinariGuard
		toads	N	NON-BACKUP LOAD-N	1

Cable	No.	One	End	The Other End	
Type	INO.	Component	Port	Port	Component
14	1	SmartGuard	DI2+	Generator alarm	Generator
	J. Har Coudina	DI2-	signal port	J Generator	
Signal cable 15	15	15 SmartGuard	DI1+	Position feedback signal upon grid	ATS
	SilialtGualu	DI1-	connection	Als	
		17 SmartGuard	485A2	24	DTSU666-H
	V		485B2	25	

Cable Type	No.	Cable Connection Description
Signal cable	1	Method 1: Use DO dry contacts to directly drive the SG Ready heat pump. The max. capability of the DO dry contacts is 12 V DC@1 A.  Method 2: Use a 12 V@30 mA power supply to drive the external relay. Choose the proper contact capability of the external relay according to the SG Ready heat pump port.


Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
Signal	12	EMMA	WAN	LAN	Router
cable	13	Charger	FE	LAN	Router

(Three-Phase PV+ESS Scenario + SmartGuard Networking)





#### Cable Connections (Three-Phase Inverter MAPO + ESS S1 + SmartGuard Connected to All Loads)



Cable	No.	One End		The Other End		
Type		Component	Port	Port	Component	
	1	Inverter	PV1+	Positive terminal	PV strings	
			PV1-	Negative terminal		
DC power	2	Inverter	BAT+	BAT+	ESS 1	
cable			BAT-	BAT-		
	3	ESS 1	BAT+	BAT+	ESS 2	
	9		BAT-	BAT-	L33 2	
	4	ESS 1	COM-7	COM-7		
			COM-8	COM-8		
			COM-9	COM-9	ESS 2	
			COM-10	COM-10	ESS 2	
			COM-11	COM-11		
			COM-12	COM-12	1	
		Inverter	COM: RJ45 network port	COM-3		
Signal				COM-2	ESS 1	
cable				COM-5		
				COM-4		
			COM-1	COM-1		
		Inverter	COM-3	COM-2		
			COM-7	COM-3	SmartGuard	
			COM-9	COM-4		
	10	6 .6 .	COM-5	Generator control		
	16	SmartGuard	COM-6	signal port	Generator	

Cable	No.	One End		One End	
Type		Component	Port	Port	Component
		Inverter	AC-L1	INV1-L1	SmartGuard
	_		AC-L2	INV1-L2	
	7		AC-L3	INV1-L3	
			AC-N	INV1-N	
			AC-PE	INV1-PE	
	8	Grid	L1	GRID/ATS-L1	SmartGuard
			L2	GRID/ATS-L2	
AC			L3	GRID/ATS-L3	
power			N	GRID/ATS-N	
cable	9	PDU for backup loads	L1	BACKUP LOAD-L1	- SmartGuard
			L2	BACKUP LOAD-L2	
			L3	BACKUP LOAD-L3	
			N	BACKUP LOAD-N	
	10	PDU for non-backup- loads	L1	NON-BACKUP LOAD-L1	SmartGuard
			L2	NON-BACKUP LOAD-L2	
			L3	NON-BACKUP LOAD-L3	
			N	NON-BACKUP LOAD-N	

Cable Type	No.	Cable Connection Description
Signal cable	1	Method 1: Use DO dry contacts to directly drive the SG Ready heat pump. The max. capability of the DO dry contacts is 12 V DC@1 A.  Method 2: Use a 12 V@30 mA power supply to drive the external relay. Choose the proper contact capability of the external relay according to the SG Ready heat pump port.


	Cable	No.	One End		The Other End	
	Type		Component	Port	Port	Component
	Signal	12	EMMA	WAN	LAN	Router
		13	Charger	FE	LAN	Router
			SmartGuard	DI2+	Generator alarm	Generator
cable	14	SmartGuaru	DI2-	signal port	Generator	
		<b>1</b>		DI1+	Position feedback signal upon grid connection	ATS
			SmartGuard	uard DI1-		

(Three-Phase PV+ESS Scenario + SmartGuard Networking)






#### **System Commissioning**





#### Setup Wizard (Connecting to the EMMA WLAN for Commissioning)




(Single-Phase PV+ESS Scenario + SmartGuard Networking)











#### Viewing the Plant Status












#### On/Off-Grid Control Parameters

#### **Enabling Off-Grid Mode**















#### **Setting Seamless Switchover**
















#### **Grid-tied Point Parameters**









## 7


#### **Physical Layout of Smart PV Optimizers**

# 





#### Generating a Physical Layout on the App Automatically







#### Creating a Physical Layout on the App Manually

